




# How to use the UC bike pumps

## Presta (thin) valve – most road bikes



1 Presta or Dunlop valves are thin. Remove black cap if it has one.

2 Unscrew the little nut to open valve.



3 Attach the **GREY** coloured end of pump nozzle to valve.

4 Flip lever **UP TO LOCK** it on, and start pumping.



5 Pump to **APPROPRIATE TYRE PRESSURE** – see tyre rim for details



6 Before removing the pump, flip lever **DOWN TO UNLOCK**.

## Schrader (fat) valve – most mountain bikes



1 Schrader valves are wider than Presta valves.

2 Remove the valve cap.



3 Attach the **BLACK** coloured end of pump nozzle to valve.

4 Flip lever **DOWN TO LOCK** it on, and start pumping.



5 Pump to **APPROPRIATE TYRE PRESSURE** – see tyre rim for details



6 Before removing the pump, flip lever **UP TO UNLOCK**.

For more info:  
[www.sustain.canterbury.ac.nz/transport/cycling](http://www.sustain.canterbury.ac.nz/transport/cycling)